


MANUAL

SW200



AUTOMATIC ENTRANCE SPECIALISTS

Content

| | | |
|-----|--|-------|
| 1 | Technical Parameters | 1 |
| 2 | Components | 2 |
| 3 | Installation step | 3-10 |
| 3.1 | Installation of bottom plate | 3 |
| 3.2 | Installation of bottom plate | 4 |
| 3.3 | Installation of pull bar | 5 |
| 3.4 | Installation of pull bar | 6 |
| 3.5 | Installation of push bar | 7 |
| 3.6 | Installation of push bar | 8 |
| 3.7 | Finished installation | 9 |
| 3.8 | Machanism and cover installation | 10 |
| 4 | Wired digram | 11-13 |
| 4.1 | Terminal details of controller | 11 |
| 4.2 | Date setting | 11 |
| 4.3 | Connection of commonly used and special function | 12-13 |
| 5 | Trouble shooting | 14 |

1. Technical Parameters

Power : AC200v-250v

Working speed: 3~10s

Opening time: 1~60s

Temperature: -20 °C ~ +55 °C

Protection class: IP12D

Weight: 6.5Kg

Dimension: SW200 515×95×80mm(L*H*W)

mm=Door width




Suitable range


kg=Door weight








Limit range



1. Components




SW200

| | |
|---|--------------|
|  | Bottom panel |
|  | Pull bar |
|  | Cover |
|  | Pull guider |
|  | Mechanism |

3. Installation step


3.1 Installation of bottom plate Pull bar type



3. Installation step

3.2 Installation of bottom plate



Push bar type



3. Installation step

3.3 Installation of pull bar guider



A. Right position



3. Installation step



3.4 Installation of pull bar guider

B. Left position



3. Installation step



- 3.5 Installation of push bar
 - A. Right position



Adjust the push bar length by two screw according to the door frame's depth(L).

3. Installation step

3. 6 Installation of push bar
B. Left position




Adjust the push bar length by two screw according to the door frame's depth(L).


3. Installation step

3.7 Finished installation

Pull bar: Door leaf open toward inside (same direction as operator)




Push bar: Door leaf open toward outside (opposite direction as operator)




3. Installation step

3.8 Mechanism installation




Hang the mechanism on the fixed base cover with screws.

3.9 Assemble and disassemble of the mechanism up cover.




4. Wired diagram

4.1 Terminal details




4.2 Date setting

| Code no. | Value range | Default value | Details |
|----------|-------------|---------------|--|
| 01 | 30-99 | 53 | Opening speed |
| 02 | 30-99 | 43 | Closing speed |
| 03 | 5-29 | 9 | Buffer speed when opening |
| 04 | 5-29 | 8 | Buffer speed when closing |
| 05 | 1-5 | 1 | Force of push and opening |
| 06 | 0-5 | 0 | Closing force when closed |
| 07 | 0-1 | 0 | Open model (0: push and go) (1: push not go) |
| 08 | 0-1 | 0 | E-lock model (0: lock with remote) (1: lock automatically when close) |
| 09 | 0-60 | 2 | Opening time |
| 10 | 5-30 | 15 | Learning speed |



4. Wired Diagram

Wiring connection of electronic lock




Inter-lock




Synchronous



24G Microwave sensor




UPS




4. Wired Diagram


Anti-clamp sensor when opening




Anti-clamp sensor when closing




Push button PB01



Access keypad AK02



Access keypad AK04



Notes:

1. Add remote:

Press button "Learn" until the led turn from yellow to red, then push any button on remote. When the led is not red, add successfully.

2. Delete remote:

Press button "Learn" until the led turn from yellow to red and then to yellow again (don't release button), press any button on remote, the led flash. Delete successfully.

3. Exit only function:

Connect outside sensor or button to terminal "Open-B", connect inside sensor or button to terminal "Open-A". Then press "full lock" button on remote.

5. Trouble shooting

| Symptoms | Causes | Items Checked | Remedies |
|---|---|--|--|
| Door opened or closed un-smoothly | Opening/closing speed is set too slow | check the opening/closing speed | speed up the opening/closing speed |
| | learning speed is too fast | check the learning speed | slow down the learning speed |
| | Too much resistance | check whether there is something on the door's working way | clear the obstacle away |
| Hit the door frame suddenly when closing, door stop suddenly when opening | Buffer speed when opening/closing is too fast | | slow down the buffer speed when opening/closing |
| | Position stopper is loosen. | | Fix the stopper. |
| Door doesn't work | No power | check the power switch, connection terminal from motor to controller | connect the power |
| | learning speed is too slow | | speed up the learning speed. |
| | Door is locked | check whether the door is locked. | un-lock the door |
| | Obstacle in the pull bar's guider. | check the pull bar guider | remove the obstacle |
| | Resistance force is too stronge. | | Power off, push the door leaf. Make sure the door work smoothly. |