


decakila



**KUEN001W
STEAM IRON**




CONTENTS

CHARACTERISTICS AND STRUCTURE	01
HOW TO FILL WATER	02
HOW TO DRY IRONING	02
HOW TO SPRAY	02
HOW TO IRON WITH STEAM	02
HOW TO USE STRONG STEAM	02
ATTENTIONS	03

CHARACTERISTICS AND STRUCTURE

The products has many functions such as temperature regulating, Spraying, Dry Ironing, Normal Steam, Burst Steam, Self-Cleaning, etc. and is with characteristics: luxury shape, high heat efficiency, easy using, good ironing result work saving and time saving, and so on.



- A: Steam selector
- B: Shot of steam button
- C: Spray button
- D: Indicator light
- E: Power cord
- F: Temperature setting dial
- G: Water inlet cover
- H: Soleplate
- I: Spray
- J: Water inlet cover
- K: Self clean button
- L: Skirt

HOW TO FILL WATER

Pull up the cap of water filling mouth, fill until full, push the cap back to its original position.

HOW TO DRY IRONING

1. Turn the temperature regulating knob to “0” position, turn the steam knob to “0” position, put the plug into the socket.
2. Turn the temperature regulating knob to the temperature scale which the ironed clothes required, the indicator will light on, then put the iron on the smooth and stable place vertically.
3. After the indicator turn off, you can begin to iron.

HOW TO SPRAY

Press the spraying button repeatedly, water will spray out from the spraying mouth, at the time, you should keep enough water in the water tank.

HOW TO IRON WITH STEAM

1. Fill water in the water tank.
2. Use steam ironing, turn the steam knob to the “1, 2, 3” position, the method for regulating temperature is the same with dry ironing.
3. After indicator turn off, turn the steam knob to the “1, 2, 3” position, steam will spray, you can start to iron.
4. After ironing complete, turn the temperature regulating knob to the “0” position, pull out the plug, take off the water tank, pour out the remaining water, turn the steam knob to the “0” position.

HOW TO USE STRONG STEAM

Press down the strong steam button, the base plate will spray out a strong steam. Attention: Strong steam must be used in steam ironing. (The temperature regulating knob must be turned to the steam section).

ATTENTIONS

- Please read the owner's manual before using the product.
- Before using, please check the voltage of the product if it is the same with the one in your home.
- When using steam ironing, you are recommended to use distilled water.
- During the iron is electrified, operator must not leave, must not let children touch the iron.
- When filling water or pouring out remaining water. Please pull out the plug first.
- After using, turn the temperature regulating knob to “0”, pull out the plug, put the iron on the smooth and stable place vertically.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- The iron is not to be used if it has been dropped, if there are visible signs of damage or if it is leaking.
- The iron must not be left unattended while it is connected to the supply mains
- The plug must be removed from the socket-outlet before the water reservoir is filled with water
- The iron must be used and rested on a stable surface.
- When placing the iron on its stand, ensure that the surface on which the stand is placed is stable.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety
- Children should be supervised to ensure that they do not play with the appliance.



decakila



decakila



decakila

Made in China Suzhou China. 2021.D01

www.decakila.com Decakila Co., Limited