


decakila



KUHS014W
HAIR STRAIGHTENER



CONTENTS

FEATURES	01
BENEFITS	01
GENERAL CAUTION	01
OPERATION STEPS	03
HINT	03
CLEANING AND CARE	03
RATING	03
DISPOSAL AND THE ENVIRONMENT	04

FEATURES

1. Fast heating Aluminium plates
2. On/off switch
3. PTC heater
4. Lock/Release function for good storage.
5. 1.8m power cord
6. 360°swive power cord to prevent tangling

BENEFITS

- a. The plates create silky smooth hair and help to protect your hair.
- b. Prevents static electricity in your hair
- c. For all hair lengths
- d. Consistent heat delivery
- f. Sleek and lightweight

GENERAL CAUTION

To reduce the risk of fire, burns, electric shock or injury, before actually using your hair styler a careful study of the following important safety precautions is strongly recommended:



1. WARNING! THIS APPLIANCE MUST NOT BE TAKEN INTO BATHROOM.
2. DO NOT IMMERSE IN WATER OR ANY OTHER LIQUID

3. DO NOT USE WITH WET HANDS
4. DO NOT WRAP THE POWER CORD AROUND THE PLATES WHEN HOT, OR WHEN STORING.
5. The appliance is VERY HOT when in use. Take care to avoid contact between the hot surface of the plates and bare skin, particularly around hands, face and neck when in use.
6. This appliance should NEVER be stored when hot or when connected to the socket. Always ensure the appliance is switched off, unplugged from socket and it has been cooled down before storing.
7. The appliance must never be left unattended when plugged in.
8. This appliance is intended for household use only. It is not intended for commercial use and outdoor use. Use the appliance only for its intended use as described in this manual.
9. The plates will become VERY HOT during operation so do not touch this part of the appliance when it is switched on or just after it has been turned off. ALLOW AT LEAST 30 MINUTES TO COOL DOWN BEFORE PUTTING AWAY
10. Close supervision is necessary when this appliance is used near or by children. Always keep it in a safe place. DUE TO THE HIGH TEMPERATURES AND FAST HEATING TIME, it is better that CHILDREN DO NOT USE this appliance.
11. Never continue to use this appliance if it is not working properly, or it has dropped in water or any other liquids, or it has damaged plug or cord. Appliance should be discarded or sent to your local distributors or its service agent or similarly qualified persons to repair.
12. If the plates are broken then do not use the appliance any more
13. Keep the power cord away from hot surfaces.
14. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
15. Children should be supervised to ensure that they do not play with the appliance.

OPERATION STEPS

1. Fully unwind the power cord.
2. Plug in the appliance to a properly power, Open the lock
3. Switch on the appliance & set the temperature you want and wait for 3 to 5 minutes before you using it.
4. For straightening hair, it is better to wash your hair first then dry with towel.
5. DO NOT HOLD THE HAIR BETWEEN THE PLATES FOR ANY MORE THAN A COUPLE OF SECONDS
6. When you have finished one section then move to another area of hair.

HINT

Always experiment on a small area of hair first to ensure you achieve the results you want.

CLEANING AND CARE

1. The appliance must be always unplugged before cleaning.
2. Do not touch the ceramic plates for at least 30 minutes after turning off. Wipe with a damp cloth to clean the ceramic plates and body.
3. Do not use any harsh detergents, abrasives, solvents or cleaners. Never immerse in water to clean.
4. Dry thoroughly before use again.

RATING

This appliance is designed to operate at the following voltages without adaptation:

Voltage: 120V~ 60Hz

Power consumption: 30W

DISPOSAL AND THE ENVIRONMENT

1. Do not dispose of the appliance in your normal domestic waste.
2. Dispose of the appliance through an approved disposal centre or at your community waste facility.
3. Observe the currently applicable regulations.
4. In case of doubt, please contact your waste disposal centre.
5. Dispose of the packaging materials in an environmentally responsible manner.





decakila



decakila



decakila

Made in China Jiangsu China. 2021.D02

www.decakila.com Global Links Technology Co. Pte. Ltd.