


## FICHA TÉCNICA

Bolsas De Empaque Al Vacio Con Zipper - 10 Und 26X34Cm Para Usar Con La Maquina Ts011.



**CÓDIGO:**  
**TS010-A**



**\*Nombre:** Bolsas empaque al vacio con zipper - 10 Und

**¿Dónde usarlo?:** Hogar, Cocina, etc

**Código de Barras:** HUN4257A182

**Código de producto:** TS010-A

**Marca:** GENERICO

**Peso (Kg):** 0.23

**Procedencia:** Importado

## INFORMACIÓN ADICIONAL

Bolsas De Empaque Al Vacio Con Zipper - 10 Und 26X34Cm.

Las Bolsas Son Perfectas Para Mantener Alimentos Frescos Ya Sea Que Esten Refrigerados O En La Despensa.


Las Bolsas Sellan La Frescura Al Bloquear El Aire Y La Humedad, Dos De Las Principales Causas Del Deterioro De Los Alimentos.

Están Diseñados Con Una Construcción Única De Múltiples Capas Que Crea Una Barrera Hermética Alrededor De Los Alimentos: Mientras Que Los Canales Especialmente Diseñados Permiten La Eliminación Completa Del Aire.


Reutilizable Y Resellable Para Alimentos De Uso Frecuente.



## USAGE OF VACUUM BAG



Put food in bag



Press the bag opening to tightly fasten the zipper



Align the nozzle of the vacuum machine with the valve  
Start the vacuum



After the air in the bag is completely removed, Vacuum machine automatically stops working



**FRIDGE FRESH KEEPING**  
LOW TEMPERATURE CAN-20°  
FROZEN MEAT PACKAGES CAN BE REFRIGERATED AT LOW TEMPERATURES - 20 DEGREES



## HEATING IN MICROWAVE OVEN

THE MATERIALS ARE ALL FOOD GRADE, WHICH CAN MEET THE HIGH TEMPERATURE IN HIGH TEMPERATURE COOKING WITHOUT HARMFUL ODOR. NO SHRINKAGE DURING HEATING

