

decakila




KUER002W
RICE COOKER



CONTENTS

KNOW YOUR RICE COOKER	01
IMPORTANT INFORMATION	02
HOW TO USE	02
POINTS TO REMEMBER	03
CARE AND CLEANING	04
IMPORTANT SAFEGUARDS	04
SAVE THESE INSTRUCTIONS	05
HOW TO USE THE STEAMER	05

KNOW YOUR RICE COOKER



Attention: 1 cup of rice means 1 cup of uncooked rice. 2 cups of rice means 2 cups of uncooked rice, and so forth. This appliance is for household use only.

Line cord safety tips

- Never pull on or yank off the cord of the appliance.
- To insert the plug, grab it firmly and guide it into the outlet.
- To disconnect the appliance, grab the plug and remove it from the outlet.
- Before each use, inspect the line cord for cuts and/or abrasion marks. If any are found, the appliance should be serviced and the line cord replaced.
- Do not operate the appliance if the line or supply cord shows any damage or if the appliance works intermittently or stops working entirely.

IMPORTANT INFORMATION

Read before using the rice cooker for the first time:

- Read all instructions.
- Wash the inner pot, cover, measuring cup, and spatula in warm, soapy water. Rinse and dry thoroughly.
- Never immerse the outer pot in water.
- Never place liquid in the outer pot. Liquid may be placed only into the inner pot.
- Never try to force the cook lever to stay in the "Cook"

position after it has shifted automatically to the "Warm" position.

- Always place the inner pot inside the outer pot before plugging in the rice cooker.
- When plugging in the cooker, always make sure that the inner pot contains liquid, or be ready to immediately add oil, butter, or margarine to the inner pot.
- Save these instructions and refer to them often.

NOTE: always wipe down the outer surface of the inner pot before placing it inside the cooker. Any moisture remaining on the inner pot surface may cause a cracking noise while the unit is heating up. Except for the actual cooking area, keep all surfaces dry to prevent any damage to the inner workings of the appliance while it is operating.

HOW TO USE

The measuring cup provided has a capacity of 160g.

1. Before placing the inner pot into the cooker, make sure that the heating plate and the outside surface of the inner pot are clean and dry. Do not allow loose rice or food particles to fall into the cooker. The inner pot must fit snugly into the heating plate to ensure proper contact for cooking. Place desired amount of rice into the inner pot. Add cold water up to the exact level indicated inside of the inner pot. Add oil, butter, or

margarine to prevent the rice from sticking. For example, for "4" measuring cups of uncooked rice, fill the inner pot with water to the "4" level mark. If too much water is added, the unit may boil over.

2.The taste and texture will vary depending on the quality/type of rice and the length of time that it is cooked. For softer, fluffier rice, add a little more water. For firmer, crunchier rice, add a little less water. You may need to experiment to suit your taste. Note that brown rice takes longer to cook than white rice and requires more water.

3.Place the lid on the rice cooker. Plug the appliance into a standard electrical outlet. The "Warm" indicator light will come on. Push the "On" switch down and the "Cook" indicator light will turn on. As the rice expands and cooks, steam will come out of the vent on the lid. Do not place the cooker directly under your cabinets; slight spattering is normal.

NOTE: Cooking will begin only when the "On" switch is pushed down and the inner pot is in position inside the unit.

4.When the cooking is done, the cooker will automatically switch to "Warm" (that is to say, the "Warm" indicator light will turn on) and will remain that way until the unit is unplugged. Rice can be kept warm for several hours in this way. For the best results, let the cooked rice sit for 15 minutes before stirring or removing it from the pot: this allows the

steam to finish the cooking process.

5.Fluff the rice with a plastic or wood utensil and mix in ingredients such as minced vegetables, if desired.

6.When done, unplug the unit. Always clean the cooker thoroughly as soon as possible after each use.

POINTS TO REMEMBER

- Do not turn on the rice cooker when there is no liquid inside it.
- Avoid placing the unit under any wall cabinets when operating, since much steam is released from the working unit. Avoid reaching over the unit when it is in use
- Use clean water to fill the water reservoir before each use. Do not use wine, broth, or any other liquids. Do not add anything to the water. Do not pour water to a level exceeding the "MAX" level
- Cooking times are estimates and depend on the quantity, size, desired degree of doneness and temperature of food.
- Cooking times may lengthen or shorten according to personal taste
- Use hot pads or oven mitts when removing the lid from the rice cooker. Open the lid carefully in order to allow steam to escape safely.
- A bit of water may remain in the water reservoir even after the rice cooker is turned off; this is entirely normal.

- Do not use any parts inside the microwave or on any cooking/ heated surface.
- Unplug the appliance after done cooking.
- Allow the unit to cool before cleaning it.

CARE AND CLEANING

- This appliance requires little maintenance.
- Never open or remove the bottom cover of the unit. Do not attempt to repair the appliance yourself. Refer the equipment to qualified personnel if servicing is needed. Unplug cord from outlet. Before washing, allow the rice cooker to cool.
- Never immerse the outer pot in water.
To clean the inner pot, cover, measuring cup, and spatula:
- Wash in hot, soapy water. Rinse and dry all parts thoroughly.
- Do not use abrasive cleaners.
- To store: Unplug the unit. Store it in its box in a clean, dry place. Never store it while it is hot or while it remains plugged in. Make sure to clean the item before storing it. Never wrap the cord tightly around the appliance. Do not put any pressure on the cord where it enters the unit, as this could cause the cord to fray and break.

IMPORTANT SAFEGUARDS

When using electrical appliances, especially when children are present, basic safety precautions should always be followed to reduce the risk of fire. Electric shock and/or injury to persons including the following:

Read all instructions.

- Do not touch hot surfaces. Use pot-holders when removing cover or handling hot containers.
- To protect against electrical shock, do not immerse cord, plug or base unit in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Do not touch hot surfaces. Use pot-holders when removing cover or handling hot containers.
- To protect against electrical shock, do not immerse cord, plug or base unit in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Do not touch hot surfaces. Use pot-holders when removing cover or handling hot containers.
- To protect against electrical shock, do not immerse cord, plug or base unit in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.

- Unplug from outlet when not in use. Allow to cool before cleaning.
- Do not operate malfunctions or has been damaged in any manner. Return appliance to an authorized service facility for examination, repair or adjustment.
- The use of accessory attachments not recommended by this appliance manufacturer may cause injury.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot food water or other hot liquids.
- Do not use appliance for other than intended use.
- Lift and open cover carefully to avoid scalding, and allow water to drip into unit
- Do not store any materials other than the manufacturer's recommended accessories in this unit when not in use.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off" the remove plug from wall outlet.

SAVE THESE INSTRUCTIONS

- A short power-supply cord is provided to reduce the hazards resulting from entanglement or tripping over a longer cord. An extension cord may be used with care; however, its marked electrical rating should be at least as great as the electrical rating of this appliance. The extension cord should not drape over the counter or tabletop, where it can be pulled on by children or tripped over.

Caution:

To ensure continued protection against risk of electric shock, connect to properly grounded outlets only.

HOW TO USE THE STEAMER

- Many other foods may be cooked in the Rice Cooker/Food Steamer including meat, fish, poultry, vegetables, or even puddings and cakes.
 - Steam cooking is quick and easy, but more importantly, it preserves the original and nutritional value.
1. To steam cook, add water to the Rice Bowl and place the steamer onto the inner rim of the Rice Bowl.
Never put any liquid into the base.
 2. Put the food in the steamer and place the lid on the Cooker
 3. Plug cord into 120V outlet. Depress the switch (COOK) to start

cooking and the red cooking indicator light will glow.

4. Steam until done to taste.

5. When removing the lid after steaming, take care not to allow water droplets to fall onto food, such as custards or puddings.

NOTE: Steam cooking times will vary depending on the food being cooked and the desired degree of cooking. Experiment with this healthy method of cooking by varying the quantity of water and the cooking time. This will help you to obtain the best results to suit your individual taste.



decakila



decakila



decakila

Made in China Jiangsu China. 2021.D01

www.decakila.com Global Links Technology Co. Pte. Ltd.