USER MANUAL

1. GENERAL INFORMATION

- 1.1 Information about the user manual
- 1.2 Key to symbols
- 1.3 Liability and Warrantees

2. SAFETY

- 2.1 General information
- 2.2 Safety instructions for the commercial use of the device
- 2.3 Intended use

3. INSTALLATION AND OPERATION

- 3.1 Safety instructions
- 3.2 Assembly and set-up
- 3.3 Operation
- 3.4 Notices for the user
- 3.5 Fitting the shelves
- 3.6 Cleaning the condenser
- 3.7 Storing food
- 3.8 Defrosting procedure

4. TEMPERATURE CONTROLLER

5. CLEANING AND MAINTENANCE

- 4.1 Safety advice
- 4.2 Cleaning
- 4.3 Safety instructions for maintenance
- 6. TROUBLESHOOTING
- 7. DISPOSAL
- 8. TECHNICAL SPECIFICATIONS
- 9. ELECTRICAL GIAGRAM

1. GENERAL INFORMATION

1.1 Information about the user manual



This user manual contains information about the installation, operation, and maintenance of the device and should be referred to as an important source of information and reference guide. Awareness of the safety instructions and instructions for use in this manual will ensure the safe and correct use of the device. In addition to the information given here, you should comply with any local Health and Safety Controls and generally applicable safety regulations. The instruction manual forms part of the product and should be kept near the device and easily accessible for anyone carrying out the installation, servicing, and maintenance or cleaning of the device.

1.2 Key to symbols

In this manual, symbols are used to highlight important safety instructions and any advice relating to the device. The instructions should be followed very carefully to avoid any risk of accident, personal injury, or material damage.



Caution!

This symbol highlights hazards, which could lead to injury. Please follow the instructions very carefully and proceed with particular attention in these cases.



WARNING! Electrical Hazard!

This symbol draws attention to potential electrical hazards. If you do not follow the safety instructions, you may risk injury or death.



NOTE! Operating Instructions

This symbol highlights instructions which should be followed to avoid any risk of damage, malfunctioning and/or breakdown of the device.



Read User Manual

This symbol highlights tips and information which have to be followed for an efficient and trouble-free operation of the device.

1.3 Liability and Warrantees

All the information and instructions in this manual take into account standard safety regulations, current levels of technical engineering, as well as the expertise and experience we have developed over the years. The instruction manual was translated with all due care and attention. However, we do not accept liability for any translation errors. If the delivery consists of a special model, the actual scope of delivery may differ from the descriptions and illustrations in this manual. This is also the case for special orders or when the device has been modified in line with new technology.



NOTE!

Read the instruction manual carefully before using the device. The manufacturer does not accept liability for any damage or malfunction resulting from not following the instructions for use.

The instruction manual should be kept near the device, easily accessible for anyone wishing to use it. We reserve the right to make technical changes for purposes of developing and improving the useful properties.

2. Safety



This section provides an overview of all important safety aspects.

In addition, every chapter provides precise safety advice for the prevention of accidents which are highlighted by the use of the above mentioned symbols. Furthermore, attention should be paid to all pictograms, markers and labels on the device, which must be kept in a permanent state of legibility. By following all the important safety advice you gain an optimal protection against all hazards as well as the assurance of a safe and trouble-free operation.

2.1 General Information

This device is designed in accordance with the presently applicable technological standards. However, the device can pose a danger if handled improperly and inappropriately. Knowing the contents of the instruction manual, as well as avoiding mistakes, and thus operating this device safely and in a fault-free manner, is very essential to protect yourselves from the hazards.

2.2 Safety Instructions for the Commercial Use of the Device

- 1. The appliance is intended for commercial or similar use (to be used by a layman in shops).
- 2. DO NOT use the appliance outdoors.
- 3. DO NOT attempt to service the item yourself.
- 4. DO NOT use damaged appliances. If you are in any doubt, consult service agent.
- 5. DO NOT use electrical devices inside the appliance (e.g. heaters, ice-cream makers etc.), unless they are of the type recommended by the manufacturer.
- Keep ventilation openings in the appliance enclosure or in the built-in structure clear of obstruction.
- 7. DO NOT use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.
- 8. DO NOT damage the refrigerant circuit.
- 9. DO NOT place combustible, explosive or volatile articles, corrosive acids or alkalis or liquids in the appliance.
- 10. DO NOT use this appliance to store medical supplies.
- 11. DO NOT allow children to play with the packaging. Dispose plastic bags safely.
- 12. Always carry, store, and handle the appliance in a vertical orientation. Move the appliance by holding its base.

- 13. Always switch off and disconnect the power supply before cleaning.
- 14. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- 15. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- 16. Children should be supervised to ensure that they do not play with the appliance.
- 17. For indoor used only. Not suitable for installation in an area where a water jet could be used. Must not be cleaned by a water jet.
- 18. To guarantee safe operation, ensure that the appliance is set up and connected as described in the instruction manual.
- 19. Any repairs and work on the appliance should only be carried out by the customer service department.

2.3 Intended Use



ATTENTION!

Only use this appliance for cooling and storage of food and beverage for commercial purposes.

3. INSTALLATION AND OPERATION

3.1 Safety Instructions



WARNING! Electrical Hazard!

Connect the device to a properly installed and grounded power socket. Never yank cord to disconnect from outlet.

Cable must not touch any hot parts.

- See that the cable does not touch any heat sources or sharp edges. Do not let the cable dangle over the cabinet edge.
- Do not use the device if it does not function properly, has been damaged
- Do not use any accessory or spare parts that have not been recommended by the manufacturer. These can be dangerous for the user or lead to damages to the device or cause personal injury. Warranty may be voided in such cases.
- Do not lay the cable over carpets or heat insulations. Do not cover the cable. Keep the cable away from operating range and do not dunk it into water.
- For your personal safety, this appliance must be properly grounded (earthed).



WARNING! WARNING! Electrical Hazard!

The device can cause injuries due to improper installation! Before installation the local power grid specification should be compared with that of the device (see type label). Connect the device only in case of compliance! Take note of the security advice!

3.2 Installation and Connection



ATTENTION!

Connection and Installation of the device may be performed by qualified personnel only.

- Unpack individual parts of the equipment. Remove the protective foil.
- The appliance must be located in a safe place and on an even surface which can bear the weight of the device.
- Never place the device on a flammable base (e.g. on a tablecloth, carpet etc.).
- Do not place the device near open fire sources, electric ovens, heating stoves or other heat sources, for example, directly sunlight. Exposure to high temperatures may cause damage to the device surface or may have an effect the cooling power of the device and its energy consumption.
- The device location should have proper air circulation. Minimal distances are: 5 cm from the back, 10 cm from the sides and 30 cm from the top of the device.
- Ventilation holes must never be covered.
- Do not place the device in areas with high air humidity, as it may cause damage to the device.
- The device should not block the access to the plug.



NOTE

If the appliance has not been stored or moved in an upright position, let it stand upright for about 12 hours before operations. If in doubt, allow the appliance to be stand.

3.3 Operation

- Clean the device prior to first use.
- Clean the insides of compartments with a disinfectant suited for the food sector.
- Clean the outside of the device with a damp, soft cloth. Dry the device thoroughly.
- Plug the mains plug into an earthed outlet.
- Turn the device on with the mains switch on the front of the display.

3.4 Notices for the User

- Only fill the refrigerated cabinet once it has reached the desired temperature (see display).
- Do not put any warm foods or liquids, as well as uncovered food, into the refrigerated cabinet.
- Close or wrap the food well.
- Do not impair free air circulation through overfilling.
- When filling the refrigerated cabinet for the first time, only open and fill one compartment at a time to prevent the device from toppling.
- Wait some time before opening the device's doors again.

- To prevent loss of refrigeration, only open the doors briefly to prevent loss of cooling energy. Also, do not open doors too frequently.
- In case of a sudden power loss, do not open the doors to prevent loss of cooling air.
- After loss of power or pulling the mains plug, do not reconnect the device to the power supply for at least 5 minutes.

3.5 Fitting the shelves

Place one set shelf guides on left side and right side of shelf support at the needed height. The height can be adjusted by holes on the support. And then insert the shelf into the shelf guides.

3.6 Cleaning the condenser

Often clean the condenser can extend the life of the appliance and increase the cooling performance. We commend that our agent or professional service person clean the condenser.

3.7 Storing food



ATTENTION!

To get the best results from the appliance, follow there instructions:

- Only store the foodstuffs in the appliance when it has reached the correct operating temperature.
- Do not please uncovered hot food or liquid inside.
- Wrap or cover food where possible.
- Avoid opening the doors for long time.
- Do not put the foodstuffs too full, it must be keep at 20cm distance between top of cabinet and foodstuffs, and 5cm distance between side of cabinet and foodstuffs.

3.8 Defrosting procedure

This device has two defrosting procedures: automatic defrosting and manual defrosting:

- Automatic defrosting
 - It is the default setting. During the normal operation of this device, the defrosting procedure starts every 4 hours and the duration time is 20 minutes.
 - It is the best defrosting interval and duration through the long term laboratory testing. Please do not change the settings if there is no any ice block up on the evaporator.
 - If you need to change the settings of automatic defrosting, please read carefully the instruction manual about temperature controller in this manual or contact the dealers who provided this device to you.
- Manual defrosting
 - For special case, the device allows manual defrosting.
 - Press "Defrosting" button for 5 seconds enter into manual defrosting.
 - Please refer to the instruction manual of temperature controller.
 - It was put together with this manual.

4. TEMPERATURE CONTROLLER

This product uses temperature controller.

If you want to know more information and details about it, please refer to the instruction manual of this controller placed together with this manual, or contact its manufacturer directly.

5. CLEANING AND MAINTENANCE



5.1 Safety Advice

- Before repairing or cleaning the device, make sure it has been disconnected from power socket (pull the power plug!!!) and has cooled down.
- Do not use any acid agents and make sure no water is present in the device.
- To protect yourself from electric shock, never immerse the device, its cables and the plug in water or other liquids.



ATTENTION!

The device is not designed to be directly sprayed off with a water jet. Hence, you must not use pressure water jets for the cleaning of the device!

5.2 Cleaning

- The device should be cleaned regularly.
- Clean the insides of compartments with a disinfectant suited for the food sector.
- Clean the outside of the device with a damp, soft cloth. Dry the device thoroughly.
- Never use abrasive cleaning agents, e.g. abrasive scouring powder, agents containing alcohol, thinners, which could damage the plastic parts and/or the coating.
- Only use a soft cloth and make sure you never use any kind of abrasive agents or pads which could scratch the surface.
- After the cleaning procedure you should use a soft and dry cloth to wipe dry and polish the surface.

If the device is not to be used for a long period of time, do the following:

- Remove the plug from the outlet socket.
- Remove all food stuff from the device.
- Clean the inside and the outside of the device using a soft damp cloth and a mild cleaning agent. Next, wash the device with clean water and dry thoroughly.

5.3 Safety Instructions for Maintenance

Check the mains lead from time to time to ensure it isn't damaged in any way. Never use the
device if the lead is damaged. If the lead is damaged it must be replaced by a qualified
electrician.

- In case of damage or malfunction, please contact our customer service.
- Only a qualified technician, using original spare parts and accessories, should carry out repairs and maintenance of the device. Do not attempt to repair the device yourself.

5.4 Maintenance

In order to maintain the efficiency of the cooling unit for a long time, the following maintenance operations must be carried out regularly for the condenser:

- Disconnect the device from the outlet socket (remove the plug!)
- Open the cooling unit, thus providing an easy access to the condenser.



WARNING! Burn Risk!

The surface of the compressor is hot during normal use of the device. Do not touch the surface of the compressor with bare hands.



ove a vacuum cleaner or a brush over the condenser towards the ribs.

NOTE!

Handle wires gently, do not pull cables!

Close the cover after cleaning.

6. TROUBLESHOOTING

Problem	Cause	Remedy
No refrigeration	•Mains plug not in the wall	•Insert mains plug correctly
	outlet	
	Power circuit fuse defect	Check power supply
	•Loss of power	•Check power supply
Insufficient refrigeration	 Direct sunlight or heat 	•Ensure sufficient distance between the
	source nearby	refrigerated cabinet and the heat sources
		Ensure sufficient distance to the walls or
	Bad air circulation around	other objects
	the refrigerated cabinet	•Let the food cool down before storing
	 Stored food are too hot 	Avoid an overfilling of the refrigerated
		cabinet, and possibly remove dispensable
	 Refrigerated cabinet is 	food from the device
	overfilled	

If problems still persist after checking all these possible error sources, please contact customer service.

7. DISPOSAL



Discarded electric appliances are recyclable and should not be discarded in the domestic waste! Please actively support us in conserving resources and protecting the environment by returning this appliance to the collection centers (if available).

8. COMPLIANCE

All parts have undergone strict product testing in order to comply with regulatory standards and specifications set by international, independent, and federal authorizes.

Products have been approved to carry the following symbols:

